

# tesa® Adjustable Adhesive Nail for Wallpaper & Plaster 2kg

BNR 77777

Height adjustable Adhesive Nail for up to 2kg. Ideal for hanging and aligning pictures on textured and sensitive surfaces like wallpaper or plaster.

## Features

- For textured and sensitive surfaces like wallpaper or plaster
- For objects up to 2kg\* per nail or 4kg using 2 nails
- Height adjustable for straight alignment
- Removable without a trace
- Reusable with a new strip

\*For optimal results please read instruction leaflet

## Product Properties

• Type of tape	Double-sided adhesive	• Resistance to chemicals	No
• Transparent	no	• Solvent free	yes
• UV-resistant	no	• Suitable surfaces	Wallpaper, Plaster
• Water resistant	no	• Reusable	yes
• Humidity resistant	no	• Waterproof	no
• Oil- and grease-resistant	no	• Batteries required	no
• Ozone resistant	no	• Batteries included	no

## Technical Data

• Application temperature	min. 15° C	• Temperature resistance	5 °C
• Area of use	Indoor	from	
• Material	PS (polystyrol)	• Temperature resistance	35 °C
• Residue-free removable	yes	up to	
• Type of adhesive	synthetic rubber	• Silicone free	yes
		• Hazard material	no

## Application

How to apply – Step by step1. Get the most out of each Adhesive Strip by cleaning your surface of dirt and dust with a dust-free cloth.

2. Apply the Adhesive Strip to the rougher surface, so in the case of wallpaper or plaster, always apply it to the wall, with the blue tab facing the wall. Before using, make sure that your surface is strong enough to take the weight of the object you want to attach.

3. Press down evenly over the entire strip for at least 5 seconds and only then remove the protective foil. Pressing down like this means the flexible polymer chains are activated to form U-shaped links with the surface. It's these links that give such a secure and reliable bond, so the harder and more evenly you press, the better the bond.

4. Now apply the tesa® Adjustable Adhesive Nail by aligning it on the top edge of the strip, then folding it down. Press down evenly all over the entire nail for at least 5 seconds.

5. The tab should be left accessible behind your object or below the nail for easy removal.

6. Push the red toggle up to unlock the nail head, adjust it to the desired position, then lock the head in place by pushing the red toggle back down until it clicks into place.

# tesa<sup>®</sup> Adjustable Adhesive Nail for Wallpaper & Plaster 2kg

## Application

## Disclaimer

tesa<sup>®</sup> products prove their impressive quality day in, day out in demanding conditions and are regularly subjected to strict controls. All information and recommendations are provided to the best of our knowledge on the basis of our practical experience. Nevertheless tesa SE can make no warranties, express or implied, including, but not limited to any implied warranty of merchantability or fitness for a particular purpose. Therefore, the user is responsible for determining whether the tesa<sup>®</sup> product is fit for a particular purpose and suitable for the user's method of application. If you are in any doubt, our technical support staff will be glad to support you.



For latest information on this product please visit  
<http://l.tesa.com/?ip=NaN>