



Product Information



Adhesive tabbing tape

Product Description

tesa[®] 54988 is a transparent tabbing tape featuring a PET backing with a synthetic rubber adhesive that is used for removing film liner of tesa[®] ACX^{plus} assortments.

Features and benefits include:

- Transparent for an easy and secure positioning
- High stiffness for good workability
- White finger-lift for accurate application

Application Fields

• Finger-lift for fast liner removal on roll application and die cuts

* For straight tabbing applications, commonly used for bridging to remove the liner from several pieces of tape and/or die cuts in just one operation

Technical Information (average values)

The values in this section should be considered representative or typical only and should not be used for specification purposes.

Product Construction

•	Backing material	PET film	•	Total thickness	200 µm
•	Type of adhesive	synthetic rubber	٠	Color	transparent

Additional Information

Suitable solution as manual tabbing tape application of ACX^{plus} 78xx PV29, ACX^{plus} 745xx PV29 and ACX^{plus} 771xx PV28.

Standard dimension: 10 mm x 30 mm incl. 10 mm finger-lift

Application guide:

* Apply with 20 N/cm at 15°C to 40°C preventing air entrapment

* Recommended dwelling time is 30 minutes before use

* Best performance is achieved by starting tabbing/ liner removal at a very fast speed of about 2 m/s and at an angle less than 45° between liner and tape.

For latest information on this product please visit http://l.tesa.com/?ip=54988





Product Information

Additional Information

For more details please refer to "Tips and Tricks for tesa ACX^{plus} Tabbing."

Disclaimer

tesa[®] products prove their impressive quality day in, day out in demanding conditions and are regularly subjected to strict controls. All information and recommendations are provided to the best of our knowledge on the basis of our practical experience. Nevertheless tesa SE can make no warranties, express or implied, including, but not limited to any implied warranty of merchantability or fitness for a particular purpose. Therefore, the user is responsible for determining whether the tesa[®] product is fit for a particular purpose and suitable for the user's method of application. If you are in any doubt, our technical support staff will be glad to support you.