



# tesa® 6038

## Product Information



Dispenser de banco semiautomático

### Descripción del producto

tesa® 6038 es un dispensador que permite ajustar la longitud deseada de cinta. Gracias a su estructura metálica, esta especialmente indicado para un uso industrial. La longitud de cinta predeterminada se dispensa presionando la palanca. La cinta se corta con una cuchilla de diente de sierra manualmente. La longitud máxima de cinta que se puede ajustar es de 10 cm. El dispensador tesa® 6038 ofrece una ventaja especial: el modo de trabajo puede ser modificado del habitual, al dispensar tiras con una pestaña no adhesiva de 5mm (doblando la punta de la cinta)

### Características

- The tesa® 6038 dispenser offers a special advantage: the mode of operation can be changed to dispensing strips with a non-adhesive tab of 5mm length (by folding the tape end).

### Aplicación

To insert the tesa® roll the blue plastic cover has to be removed: push the metal knob at the back of the dispenser and lift the cover. The tesa® tape is placed onto the tape wheel and the start of the tape is put adhesive side down on the upper transporting roller. Replace the cover to make the tesa® 6038 automatic dispenser ready for use. To alter the tape length loosen the nut beside the transport lever and adjust the dial to the required length. If strips with a non-adhesive tab are required, move the small lever at the front of the cover to the right.

### Propiedades / Valores de rendimiento

• Core diameter	3	• Modo de operación	manual
• Diámetro máximo del rollo	140 mm	• Roll width max	30 mm
• Fijado le longitud	100 mm	• Tipo de aplicación	multifuncional
• Gramaje	2600 g		

### Disclaimer

tesa® products prove their impressive quality day in, day out in demanding conditions and are regularly subjected to strict controls. All information and recommendations are provided to the best of our knowledge on the basis of our practical experience. Nevertheless tesa SE can make no warranties, express or implied, including, but not limited to any implied warranty of merchantability or fitness for a particular purpose. Therefore, the user is responsible for determining whether the tesa® product is fit for a particular purpose and suitable for the user's method of application. If you are in any doubt, our technical support staff will be glad to support you.



For latest information on this product please visit <http://l.tesa.com/?ip=06038>