




# SLEEVE SOLUTIONS


## Simplified Sleeve Solutions for Enhanced Flexibility


Recommendations for Selecting Sleeve Width Based on Harness Diameter


tesa® SupersleevePlus 51036 PV76	Harness Dia. [mm]	Sleeve Width [mm]
	<10	50
	11 - 20	95
	21 - 30	140
	31 - 40	190
	41 - 50	230
	-	-
Very high abrasion resistance and high noise damping due to layers of both cloth and fleece	-	-
	-	-

tesa® SupersleevePlus 51036 PV78	Harness Dia. [mm]	Sleeve Width [mm]
	<10	50
	11 - 20	95
	21 - 30	140
	31 - 40	190
	41 - 50	230
	-	-
High abrasion resistance and medium noise damping due to layers of both cloth and fleece	-	-
	-	-

tesa® Supersleeve 51036 PV6	Harness Dia. [mm]	Sleeve Width [mm]
	<12	67
	12 - 16	85
	16 - 19	100
	19 - 24	115
	24 - 29	130
	29 - 33	145
	33 - 38	160
	38 - 45	180
High abrasion resistance due to double layer design	45 - 49	195

tesa® Supersleeve 51036 PV7	Harness Dia. [mm]	Sleeve Width [mm]
	<10	50
	11 - 20	95
	21 - 30	140
	31 - 40	190
	41 - 50	230
	-	-
High abrasion resistance due to double layer design	-	-
	-	-

tesa® Sleeve 51036 PV9	Harness Dia. [mm]	Sleeve Width [mm]
	<13	68
	13 - 16	78
	16 - 23	100
	23 - 33	130
	33 - 41	155
	41 - 54	195
Abrasion protection, cost efficiency, and flexibility due to single layer design	-	-
	-	-

tesa® Sleeve 51036 PV5	Harness Dia. [mm]	Sleeve Width [mm]
	10 - 60	35
	>30	59
	-	-
	-	-
	-	-
	-	-
Abrasion protection and spiral application	-	-
	-	-


tesa® Supersleeve 51608 PV6	Harness Dia. [mm]	Sleeve Width [mm]
	<12	67
	12 - 16	85
	16 - 19	100
	19 - 24	115
	24 - 29	130
	29 - 33	145
	33 - 38	160
High noise damping due to double layer design	38 - 45	180
	45 - 49	195

tesa® Sleeve 68000 PV17	Harness Dia. [mm]	Sleeve Width [mm]
	<10	50
	10 - 15	68
	16 - 19	80
	20 - 25	100
	26 - 35	130
	36 - 43	160
	–	–
Aluminum laminated glass cloth for radiant heat reflection	–	–
	–	–

### Recommendations for Selecting Perforation Length Based on Harness Dimension

- 10mm of space should be left between the sleeve and the start of the branch or forks
- Spot wrapping should be used on either side of the sleeve to cover the remaining exposed wire
- Sleeve perforation is available in increments of 10mm

Example:



- Total area to be covered 400mm
- Length of sleeve: 380mm
- Leaving recommended 10mm on either side of the sleeve
- Perforation length standards 50-200mm every 10mm; 200-400mm every 20mm

#### Automotive Solution Center

tesa tape, inc.  
39550 W 13 Mile Rd. • Suite 150 • Novi, MI 48377  
Email: marketing@tesatape.com

#### tesa tape Mexico, S.A de C.V.

Av. Mina de Guadalupe 950M  
Col. Parque Industrial Santa Fe Puerto Interior  
Silao, Guanajuato C.P. 36275  
Correo electrónico: mexico@tesatape.com

ISO 9001:2008 Certified • IATF 16949:2016 Certified • ISO 14001:2004 Certified + Cor 1:2009 Certified

**Experience the Difference!**  
Scan this QR code to request samples of our Sleeve Solutions.